## Hard wire Kits:



Wall plate x 1pc Screw x 2ps Wire connector x 3ps

## Hard wired installation instructions Important:

Turn the main power off before installing. Hard-wired installation must be performed by a licensed electrician, in accordance with local & national codes.



1. Cut the power cord off 6 inches from the bushing.



2. Separate the wires, careful not to remove too much insulation



3. Thread the wires through the wall plate.



4. Connect wires to the wires from junction box. White to white, black to black and green to grounding. Make sure of there is no bare wires exposed.